



HOLZKERN

CLASSIC | KLASSIK

42 MM

Minute | Minute

Hour | Stunde

Normal position

Normalposition

1st click: time setting

1 Pos.: Zeiteinstellung

Second | Sekunde

Instructions | Anleitung

[www.holzkern.com/FAQ](http://www.holzkern.com/FAQ)

### Winding the watch

Wind the movement by turning the crown clockwise 40 times prior to wearing it. The movement will also wind automatically through regular use; however, after many hours without being worn it may be necessary to wind the movement again.

### Uhr aufziehen

Drehe die Krone 40 Mal im Uhrzeigersinn, bevor du deine Uhr zum ersten Mal anlegst und sie beginnt zu ticken.

Das Uhrwerk zieht sich nun durch deine Bewegung selbstständig auf. Sollte die Uhr mehr als 40 Stunden nicht getragen werden, wiederhole den Vorgang.

### Movement | Uhrwerk

Automatic | Automatik

Citizen-Miyota 82S0

### Case thickness | Gehäusehöhe

11,5 mm

### Circumference | Umfang

Adjustable length | Größenverstellbar

### Weight | Gewicht

75 g

### Glass | Glas

Sapphire Crystal | Saphirglas

### Backplate | Rückseite Gehäuse

Metal, glass | Metall, Glas

### Water resistance | Wasserdicht

Splash-proof | Spritzwasserfest

### Band width | Armbandbreite

24 mm

### Band | Armband

Wood | Holz

Screws | Schrauben



Accuracy / Day

±20-40 sec.

Genauigkeit / Tag

±20-40 Sek.



Running time

42 Hours

Laufzeit

42 Stunden